







# Smart Guide: iCT250 - Set the terminal to Static IP

Ingenico iCT250 - Set the terminal to Static IP

Steps	Button Commands/Action Steps	Screen Commands/Terminal Display	Helpful Info
1.	From the Welcome   Bienvenue screen, one at a time, press F2 then F3 quickly. You will be prompted for a password.	<div><div>FirstData</div><div>Welcome   Bienvenue</div></div> <div>Press F2 then F3</div>	
2.	Enter your Administrator password (the default is 222222) and press the <div></div> OK key.	<div><div>ENTER</div><div>ADMIN PASSWORD</div><div>TIDXXXXX</div><div>*****</div></div>	
3.	Select F1 for “APP”	<div><div>APP</div><div>SETTING</div></div> <div>F1F4</div>	
5.	Select F4 for “ADMIN”	<div><div>FirstData</div><div>ADMIN</div><div>TRANS</div></div> <div>F1F4</div>	
6	Select 3. SETUP	<div><div>1. SETTLEMENT</div><div>2. REPORTS</div><div>3. SETUP</div><div>4. KEY EXCHANGE</div></div>	

7	Select 3. <b>SYSTEM SETUP</b>	<div> 1. OPTIONS  2. HOST SETUP  3. <b>SYSTEM SETUP</b>  4. CLERK SETUP </div>	
8.	Enter your Administrator password (the default is 222222) and press the  OK key.	<div> ENTER  ADMIN PASSWORD  <div>*****</div> </div>	
9.	Press the  key to cycle through the options – stopping at <b>COMMS MODE</b>		
10.	Select F4 for ETHERNET	<div> COMMS MODE  DIAL <b>ETHERNET</b> </div> <div>F1F4</div>	
11.	Select 1 for DNS SETUP	<div> 1. <b>DNS SETUP</b>  2. TERMINAL SETUP </div>	
12.	Select NO (F1) for Automatic DNS and press the green OK key.	<div> AUTOMATIC DNS  <div>NOYES</div> </div> <div>F1F4</div>	
13.	Enter Primary DNS Address and press the  OK key.	<div> PRIMARY ADDRESS  + OK  <div>10.255.25.21</div> </div>	

14.	Enter Secondary DNS Address and press the  OK key.	<div>SECONDARY ADDR + OK</div>	
15.	A quick verification message will be displayed, after changed are made.	<div>DNS SETUP PLASE WAIT</div>	
16.	Select 2 for <b>TERMINAL SETUP</b>	<div>1. DNS SETUP 2. <b>TERMINAL SETUP</b></div>	
17.	Select 3 for <b>STATIC</b> and enter the IP address and press the green OK key.	<div>1. NONE 2. DYNAMIC 3. <b>STATIC</b></div>	
18.	Enter Static IP address and press the  OK key.	<div>TERMINAL ADDRESS + OK</div> <div>192.168.1.21</div>	
19.	Enter subnet Mask ID and press the  OK key.	<div>MASK ID + OK</div> <div>255.255.255.0</div>	

20.	<p>Enter Gateway address and press the  OK key.</p> <p>** Also known as the router IP address</p>	<div><p>GATEWAY ADDRESS</p><p>+ OK</p><p>192.168.1.1</p></div>	
21.	<p>After pressing the  OK key in the previous step, the device will automatically restart.</p>	<div><p>Terminal Setup</p><p>Please Wait</p></div>	
22.	<p>You will return to the Welcome   Bienvenue</p>	<div><p><b>FirstData</b></p><p>Welcome   Bienvenue</p></div>	