





Smart Guide: iCT250 - Perform Debit Key Exchange

Ingenico iCT250 - Countertop - Perform Debit Key Exchange

Steps	Button Commands/Action Steps	Screen Commands/Terminal Display	Helpful Info
1.	From the Welcome Bienvenue screen, one at a time, press F2 then F3 quickly. You will be prompted for a password.	<div><div>FirstData</div><div>Welcome Bienvenue</div></div> <div>Press F2 then F3</div>	
2.	Enter your Administrator password (the default is 222222) and press the OK key.	<div>ENTER ADMIN PASSWORD TIDXXXXX *****</div>	
3.	Select F1 for “APP”	<div><div>APP</div><div>SETTING</div></div> <div>F1F4</div>	
5.	Select F4 for “ADMIN”	<div><div>ADMIN</div><div>TRANS</div></div> <div>F1F4</div>	
6	Select 2. MAINTENANCE	<div>5. PRINT SETUP 6. MAINTENANCE 7. HELP DESK 8. TRAINING MODE</div>	

6	Select 1. EMV KEY DLL next press the 	<div>1. EMV KEY DLL</div>	
8.	The device will begin communicating with the First Data network. You will see the following screens.	<div>Please wait</div> <div>Connecting</div> <div>Sending</div> <div>Receiving</div> <div>Sending</div>	
8.	Once the key download is success, you will see the following Next press the  OK key	<div>EMV KEY DLL DOWNLOAD SUCCESSFUL PRESS OK TO CONT</div>	

12	Back all the way out to the First Data screen by pressing the press the red key 		
13	Enter your Administrator password (the default is 222222) and press the  OK key.	<div><p>ADMIN</p><p>PASSWORD + OK</p><p>*****</p></div>	
14.	You will return to the Welcome Bienvenue	<div><p>FirstData</p><p>Welcome Bienvenue</p></div>	