

# Smart Guide: iCT250 – Switch to Standalone

## Ingenico iCT250 - Switch to Standalone

Steps	Button Commands/Action Steps	Screen Commands/Terminal Display	Helpful Info
1.	From the Welcome   Bienvenue screen, one at a time, press F2 then F3 quickly. You will be prompted for a password.	<div><div>FirstData</div><div>Welcome   Bienvenue</div></div> <div>Press F2 then F3</div>	
2.	Enter your Administrator password and press the <div></div> OK key.	<div>ENTER ADMIN PASSWORD TID: XXXXXX  *****</div>	
3.	Select F1 for “APP”	<div><div>APP</div><div>SETTING</div></div> <div>F1F4</div>	
4.	Select F1 for “TRANS”	<div><div>ADMIN</div><div>TRANS</div></div> <div>F1F4</div>	
5.	Select 1 for “ <div>SALE</div> ”	<div><div>1 - SALE</div><div>2 - PRE-AUTH</div><div>3 - COMPLETION</div><div>4 - REFUND</div></div>	

6.	To exit Standalone mode – Press the RED X button multiple times, where you are prompted for a password.	<div>ADMIN PASSWORD + OK</div>	
7.	After successfully entering the Admin password, you will return to the Welcome Screen	<div>FirstData Welcome   Bienvenue</div>	