






# Smart Guide: iCT250 - Enable Heartbeat

Ingenico iCT250 - Countertop - Enable Heartbeat

- PRE-REQUISITE – SIPA 0125**

Steps	Button Commands/Action Steps	Screen Commands/Terminal Display	Helpful Info
1.	From the Welcome   Bienvenue screen, one at a time, press F2 then F3 quickly. You will be prompted for a password.	<div><b>FirstData</b> Welcome   Bienvenue</div> Press F2 then F3	
2.	Enter your Administrator password (the default is 222222) and press the  OK key.	<div>ENTER ADMIN PASSWORD TIDXXXXX  *****</div>	
3.	Select F4 for “Settings”	<div>APP SETTING</div> F1 F4	
4	Press the  key to cycle through the options – stopping at ENABLE HEARTBEAT		
5	<p>The iCT250 default setting is <b>NO</b> To turn on <b>SELECT F1 for YES</b></p> <p><b>** The heartbeat intermittence is every 2 second</b></p> <p><b>** VERIFY BEFORE PROCEEDING:</b> !! Client must check with their POS provider for integration and compatibility!! !! If you are un-sure – please leave this feature turned OFF=NO</p>	<div>ENABLE HEARTBEAT  YES NO NO</div> F1 F4	

6	Back all the way out to the First Data screen by pressing the press the red key 		
7	Enter your Administrator password (the default is 222222) and press the  OK key.	<div><p>ADMIN</p><p>PASSWORD + OK</p><p></p></div>	
8	You will return to the Welcome   Bienvenue	<div><p><b>FirstData</b></p><p>Welcome   Bienvenue</p></div>	